



Especificaciones

Especificación	Valor
No./mount. holes [qty.]	3 qty
O.1 [mm]	89 mm
No./mount. holes with thread [qty.]	0 qty
L.1 [mm]	334 mm
Rotation	CW
Size A [mm]	89 mm
Size B [mm]	48 mm
No./teeth	11 qty
No./teeth (fits into) [qty.]	9. 11 qty
Power	4 kW
O.3 [mm]	127 mm
O.2 [mm]	89 mm
C.1 [mm]	11.00 mm
Voltage	24 V
C.3 [mm]	11.00 mm
C.2 [mm]	11.00 mm

Aplicaciones

Marca	Vehículo	Tipos de modelo	Desde	Hasta
VOLVO	F6 F 610	TD60C	02/1980	10/1986
VOLVO	F6 F 611	TD60C	02/1980	02/1986
VOLVO	F6 F 612	TD60C	04/1983	02/1986
VOLVO	F6 F 613,F 614	TD60A	09/1975	02/1986
VOLVO	F6 F 613,F 614	TD60B	09/1975	02/1986
VOLVO	F6 F 616	TD60B	02/1981	02/1986
VOLVO	F7 F 7	TD70F	08/1978	12/1985
VOLVO	F7 F 7	TD70FS	08/1978	12/1985
VOLVO	F7 F 7	TD70G	08/1978	12/1985
VOLVO	FL FL 180-10	D6B		
VOLVO	FL FL 180-10	D6B180		
VOLVO	FL FL 180-11	D6B		
VOLVO	FL FL 180-11	D6B180		
VOLVO	FL FL 180-12	D6B		
VOLVO	FL FL 180-12	D6B180		
VOLVO	FL FL 180-13	D6B		
VOLVO	FL FL 180-13	D6B180		
VOLVO	FL FL 180-14	D6B		
VOLVO	FL FL 180-14	D6B180		
VOLVO	FL FL 180-15	D6B		
VOLVO	FL FL 180-15	D6B180		
VOLVO	FL FL 180-16	D6B		
VOLVO	FL FL 180-16	D6B180	05/2000	08/2006
VOLVO	FL FL 180-16	D6B180		
VOLVO	FL FL 180-17	D6B		
VOLVO	FL FL 180-17	D6B180	05/2000	08/2006
VOLVO	FL FL 180-17	D6B180		
VOLVO	FL FL 180-18	D6B		
VOLVO	FL FL 180-18	D6B180	05/2000	08/2006
VOLVO	FL FL 180-18	D6B180		
VOLVO	FL FL 180-19	D6B180	05/2000	08/2006
VOLVO	FL FL 180-21	D6B180	05/2000	08/2006
VOLVO	FL FL 180-26	D6B180	05/2000	08/2006
VOLVO	FL FL 180-7,5	D6B		
VOLVO	FL FL 180-7,5	D6B180		
VOLVO	FL FL 180-8	D6B		
VOLVO	FL FL 180-8	D6B180		
VOLVO	FL FL 180-9	D6B		
VOLVO	FL FL 180-9	D6B180		
VOLVO	FL FL 220-10	D6B		
VOLVO	FL FL 220-10	D6B220		
VOLVO	FL FL 220-11	D6B		
VOLVO	FL FL 220-11	D6B220		
VOLVO	FL FL 220-12	D6B		
VOLVO	FL FL 220-12	D6B220		
VOLVO	FL FL 220-13	D6B		
VOLVO	FL FL 220-13	D6B220		
VOLVO	FL FL 220-14	D6B		
VOLVO	FL FL 220-14	D6B220		
VOLVO	FL FL 220-15	D6B		
VOLVO	FL FL 220-15	D6B220		
VOLVO	FL FL 220-16	D6B		
VOLVO	FL FL 220-16	D6B220	05/2000	08/2006
VOLVO	FL FL 220-16	D6B220		
VOLVO	FL FL 220-17	D6B		
VOLVO	FL FL 220-17	D6B220	05/2000	08/2006
VOLVO	FL FL 220-17	D6B220		
VOLVO	FL FL 220-18	D6B		
VOLVO	FL FL 220-18	D6B220	05/2000	08/2006
VOLVO	FL FL 220-18	D6B220		
VOLVO	FL FL 220-19	D6B220	05/2000	08/2006
VOLVO	FL FL 220-21	D6B220	05/2000	08/2006
VOLVO	FL FL 220-26	D6B220	05/2000	08/2006
VOLVO	FL FL 220-7,5	D6B		
VOLVO	FL FL 220-7,5	D6B220		
VOLVO	FL FL 220-8	D6B		
VOLVO	FL FL 220-8	D6B220		
VOLVO	FL FL 220-9	D6B		
VOLVO	FL FL 220-9	D6B220		
VOLVO	FL FL 250-10	D6B		
VOLVO	FL FL 250-10	D6B250		
VOLVO	FL FL 250-11	D6B		
VOLVO	FL FL 250-11	D6B250		
VOLVO	FL FL 250-12	D6B		
VOLVO	FL FL 250-12	D6B250		
VOLVO	FL FL 250-13	D6B		
VOLVO	FL FL 250-13	D6B250		
VOLVO	FL FL 250-14	D6B		
VOLVO	FL FL 250-14	D6B250		
VOLVO	FL FL 250-15	D6B		
VOLVO	FL FL 250-15	D6B250		
VOLVO	FL FL 250-16	D6B		
VOLVO	FL FL 250-16	D6B250	05/2000	08/2006
VOLVO	FL FL 250-16	D6B250		
VOLVO	FL FL 250-17	D6B		
VOLVO	FL FL 250-17	D6B250	05/2000	08/2006
VOLVO	FL FL 250-17	D6B250		
VOLVO	FL FL 250-18	D6B		
VOLVO	FL FL 250-18	D6B250	05/2000	08/2006
VOLVO	FL FL 250-18	D6B250		
VOLVO	FL FL 250-19	D6B250	05/2000	08/2006
VOLVO	FL FL 250-21	D6B250	05/2000	08/2006
VOLVO	FL FL 250-26	D6B250	05/2000	08/2006
VOLVO	FL FL 250-7,5	D6B		
VOLVO	FL FL 250-7,5	D6B250		
VOLVO	FL FL 250-8	D6B		
VOLVO	FL FL 250-8	D6B250		
VOLVO	FL FL 250-9	D6B		
VOLVO	FL FL 250-9	D6B250		
VOLVO	FL6 FL 608	D6A180	01/1991	12/1999
VOLVO	FL6 FL 608	D6A210	01/1993	12/1999
VOLVO	FL6 FL 608	D6B220	01/1995	08/2000
VOLVO	FL6 FL 608	TD61G	10/1985	12/1999
VOLVO	FL6 FL 608	TD61GA	10/1985	12/1999
VOLVO	FL6 FL 608	TD63E	01/1991	12/1999
VOLVO	FL6 FL 608	TD63ES	01/1993	12/1999
VOLVO	FL6 FL 610	TD61G	09/1985	11/1994
VOLVO	FL6 FL 611	D6A180	09/1985	03/2000
VOLVO	FL6 FL 611	D6A210	12/1994	03/2000
VOLVO	FL6 FL 611	TD61G	09/1985	11/1994
VOLVO	FL6 FL 611	TD61GA	09/1985	11/1994
VOLVO	FL6 FL 611	TD61GB	09/1985	03/2000
VOLVO	FL6 FL 611	TD61GC	09/1985	03/2000
VOLVO	FL6 FL 611	TD61GS	09/1985	03/2000
VOLVO	FL6 FL 611	TD63E	09/1985	03/2000
VOLVO	FL6 FL 611	TD63ES	12/1994	03/2000
VOLVO	FL6 FL 612	D6A180	09/1985	12/1999
VOLVO	FL6 FL 612	D6A210	11/1991	12/1999
VOLVO	FL6 FL 612	D6A230	12/1995	12/1999
VOLVO	FL6 FL 612	D6A250	12/1995	12/1999
VOLVO	FL6 FL 612	D6B220	01/1995	08/2000
VOLVO	FL6 FL 612	TD61GB	09/1985	12/1999
VOLVO	FL6 FL 612	TD61GC	09/1985	12/1999
VOLVO	FL6 FL 612	TD61GS	09/1985	12/1999
VOLVO	FL6 FL 612	TD63E	09/1985	12/1999
VOLVO	FL6 FL 612	TD63ES	11/1991	12/1999
VOLVO	FL6 FL 613	D6B220	01/1995	08/2000
VOLVO	FL6 FL 614	D6A180	09/1985	03/2000
VOLVO	FL6 FL 614	D6A180	12/1995	03/2000
VOLVO	FL6 FL 614	D6A210	12/1995	03/2000
VOLVO	FL6 FL 614	D6A210	09/1985	03/2000
VOLVO	FL6 FL 614	D6A230	12/1995	03/2000
VOLVO	FL6 FL 614	D6A250	12/1995	03/2000
VOLVO	FL6 FL 614	D6B220	01/1995	08/2000
VOLVO	FL6 FL 614	TD61F	09/1985	03/2000
VOLVO	FL6 FL 614	TD61GB	09/1985	03/2000
VOLVO	FL6 FL 614	TD61GC	09/1985	03/2000
VOLVO	FL6 FL 614	TD61GS	09/1985	03/2000
VOLVO	FL6 FL 614	TD63E	09/1985	03/2000
VOLVO	FL6 FL 614	TD63ES	09/1985	03/2000
VOLVO	FL6 FL 615	D6A180	11/1991	03/2000
VOLVO	FL6 FL 615	D6A210	11/1991	03/2000
VOLVO	FL6 FL 615	D6A230	12/1995	03/2000
VOLVO	FL6 FL 615	D6A250	12/1995	03/2000
VOLVO	FL6 FL 615	D6B220	01/1995	08/2000
VOLVO	FL6 FL 615	TD63E	11/1991	03/2000
VOLVO	FL6 FL 615	TD63ES	11/1991	03/2000
VOLVO	FL6 FL 616	D6B220	01/1995	08/2000
VOLVO	FL6 FL 617	D6B220	01/1995	08/2000
VOLVO	FL6 FL 618	D6A180	11/1991	03/2000
VOLVO	FL6 FL 618	D6A210	11/1991	03/2000
VOLVO	FL6 FL 618	D6A230	12/1995	03/2000
VOLVO	FL6 FL 618	D6A250	12/1995	03/2000
VOLVO	FL6 FL 618	D6B220	01/1995	08/2000
VOLVO	FL6 FL 618	TD63E	11/1991	03/2000
VOLVO	FL6 FL 618	TD63ES	11/1991	03/2000
VOLVO	FL6 FL 619	D6B220	01/1995	08/2000
VOLVO	FL6 FL 619	TD61F	09/1985	11/1994
VOLVO	FL6 FL 621	D6B220	01/1995	08/2000
VOLVO	FL6 FL 626	D6B220	01/1995	08/2000

Código original

0001231014	0001263068
18957	21067513

Código equivalente (Fabricante del vehículo)

167822 (VOLVO)	21067513 (VOLVO)
21477589 (VOLVO)	3978044 (VOLVO)
420718 (VOLVO)	4881598 (VOLVO)
8112224 (VOLVO)	8112996 (VOLVO)
8113860 (VOLVO)	85000446 (VOLVO)
85003303 (VOLVO)	10391 (KUHNER)
10391B (KUHNER)	10391P (KUHNER)
ANM13200X (ANDEL)	811.505.113.010 (PSH)
811.505.113.016 (PSH)	811.505.113.018 (PSH)
811.505.113.210 (PSH)	811.505.113.211 (PSH)
811.505.113.215 (PSH)	811.505.113.280 (PSH)
811.505.113.310 (PSH)	S135.507 (PSH)
S145.735 (PSH)	S100678 (BTS TURBO)
025581 (DA SILVA)	19084010 (DELCO)
19084211 (DELCO)	DRS0167 (DELCO)
SER84211-12B1 (DELCO)	103421 (FARCOM)
10010716AV (ITAB AUTOMOTIVE)	10010716OV (ITAB AUTOMOTIVE)
100529 (FEBI BILSTEIN)	T001008006 (SEG AUTOMOTIVE)
11.139.613 (ISKRA / LETRIKA)	AZF4407 (ISKRA / LETRIKA)
IS9465 (ISKRA / LETRIKA)	18957N (WAI / TRANSPO)
26023211 (DIXIE)	72444498 (MAHLE)
MS774 (MAHLE)	861038 (PRESTOLITE)
BOS0001231014 (WOODAUTO)	MAHMS774 (WOODAUTO)
PRE861038 (WOODAUTO)	STR22074 (WOODAUTO)
WOOSTR22074 (WOODAUTO)	CS1474 (HC PARTS)
HCS1474 (HC PARTS)	LRS02175 (LUCAS)
LRS2175 (LUCAS)	RNL231014 (RNL)
45-3349 (ELSTOCK)	CST10716AS (CASCO)
CST10716GS (CASCO)	8644 (CEVAM)
8644R (CEVAM)	33525 (EAI)
SG0070 (GHIBAUDI)	111638 (CARGO)
F032111638 (CARGO)	8EA012586-331 (HELLA)
8EA012586-511 (HELLA)	943252208010 (MAGNETI MARELLI)
MSR701 (MAGNETI MARELLI)	5110018 (MEAT & DORIA)
88212842 (POWERMAX)	S24BH0107A2 (SIDAT)
120-20144 (ROBERT'S)	STM921 (ROLLCO)
331998 (LOGISTIK)	20401617BN (REAL)
20401617OE (REAL)	6010716.0 (SANDO)
6010716.1 (SANDO)	MAV127160A (SIOM)
STB0391 (KRAUF)	CGB-23076 (AINDE)
CGB-53349 (AINDE)	PRSE392 (3EFFE)
STRE392 (3EFFE)	STR1359 (ELECTROLOG)
STR7925 (ELECTROLOG)	PTC-4012 (POWER TRUCK)
S0107 (AS-PL)	