



Números OE

MITSUBISHI M003T21874

Código equivalente

3EFFE STRS188 STRW053

ACAUTO AC-JBS0640 AC-JBS1000

ACKOJA A32-12-52309 A32-12-52313

AINDE CGB-23501 CGB-24991

AIRSTAL 30-1928

ALANKO 10440007

ANDEL ANM15799

AS-PL S5012

ASHIKA 003-M162

ATL AUTOTECHNIK A18720

AUTOELECTRO AES0127

AUTOTEAM SMI133A

BORG & BECK BST2101

BOSCH 0986014980 0986014990 0986014991
0986018721 0986UR1111 0986UR1185
0986UR1978

BTS TURBO S104487

CARGO 110808 F032110808

CASCO CST35133AS CST35133GS

CEVAM 9658

COMLINE CST0026

DA SILVA 040028

DELCO DRS3579

DENSO 2280003380 2280003381 2280003386

DRI 324008082

EAI 11704

ELECTROLOG STR00246

ELSTOCK 25-1114

ERA 220118 220387 220387A

EUROTEC 11040062

FARCOM 103288

FRIESEN 8052309

GHIBAUDI SG0279 SG0279RB

HC PARTS JS1000

HELLA 8EA737191-001

HENKEL PARTS 3111474 3111476 3111477

HERTH+BUSS J5213035

HYUNDAI / KIA 0K24018400 0K24118400 0K24118400A
0K30A18400 0K32618400 0K90018400
36100-2Y100

ITAB AUTOMOTIVE 10035133AV 10035133OV

J&N 410-46000

KRAUF STA1000

KUHNER 201000 201098 201098V 20640

LE PART LES0267

LOGISTIK 335175

LUCAS LRS01150 LRS1150

MAGNETI MARELLI 943210001010 MSRC1000

MAPCO 13576

MAZDA B505-18-400 B593-18-400 B676-18-400
B676-18-400A B676-18-400B B6S8-18-400
B6S8-18-400A

MEAT & DORIA 5032082

MITSUBISHI M003T24482 M003T24482A M003T24482H
M003T24482HC M003T24482J M003T24482K
M003T24482L M003T24483 M003T24486H
M003T30881 M003T33282 M003T33283
M003T33581 M003T33582 M003T33582A
M003T33583 M003T33586D M003T33588
M003T38881 M003T38881A M003T38881B
M003T38881C M003T38882 M003T38882A
M003T38882B M003T38882C M003T38883
M003T38884 M003T38885 M003T39481
M003T39891 M003T43581 M003T49381
M003T49481 M003T49581 M003T49781
M003Y24482 M3T21874 M3T24482
M3T24482A M3T24482H M3T24482HC
M3T24482J M3T24482K M3T24482L
M3T24483 M3T24486H M3T30881 M3T33282
M3T33283 M3T33581 M3T33582 M3T33582A
M3T33583 M3T33586D M3T33588 M3T38862
M3T38881 M3T38881A M3T38881B
M3T38881C M3T38882 M3T38882A
M3T38882B M3T38882C M3T38883
M3T38884 M3T38885 M3T39481 M3T39981
M3T43581 M3T49381 M3T49481 M3T49581
M3T49781 M3Y24482

NPS K521A03

POWERMAX 8212160

PROTECH IR8608

QUINTON HAZELL QRS1925

REAL 20437331BN 20437331OE

RNL 1000JSRT

ROLLCO STM1058

SANDO 6035133.0 6035133.1

SIDAT S12MH0849 S12MH0849A2

SIOM MAV371330 MAV371330A

SNRA K19001

STARTCAR 704ST11

TESLA TECHNICS TT15624

THE NEWLINE RE8229N

TMI ST00406

VALEO 458187 561105 600058

WAI 140.009.083.001 140.009.083.120
140.009.083.130 140.009.083.340
140.009.083.341 140.009.083.360
140.009.083.441 140.009.083.442
140.009.083.445 16922N 16922R 17704N
17704R 17811N S145.015

WILSON 91-27-3085 91-27-3085N

Aplicaciones

MAZDA		
626 III (GD)		
2.0 (GDEP) 09/1987-10/1990	2.2 12V (GD102) 11/1987-07/1991	
2.0 12V (GDEP) 09/1987-05/1992	1.8 (GD8P) 11/1987-05/1992	
2.0 16V (GDEP) 11/1987-05/1992	2.0 16V (GDEP) 07/1987-09/1989	
1.6 (GD106) 06/1987-05/1992	1.8 08/1989-05/1992	
626 III Station Wagon (GV)		
2.0 (GVEW) 10/1988-09/1997	2.2 12V (GV102) 03/1989-11/1996	
1.8 (GV8W) 01/1988-03/1992	2.2 12V 4WD (GV102) 05/1991-11/1992	
2.2 12V 4WD (GV102) 05/1991-11/1992	2.0 12V (GVEW) 09/1987-01/1990	
2.0 16V (GVEW) 01/1988-03/1992	2.0 i 16V (GVEW) 10/1988-09/1997	
1.8 (GV8W) 10/1989-03/1992	2.0 12V 09/1987-12/1992	
323 S IV (BG)		
1.3 16V (BG3P) 04/1991-07/1994	1.3 (BG3P) 09/1989-06/1991	
1.3 16V (BG3P) 04/1991-07/1994	1.8 16V (BG8P) 08/1989-07/1994	
1.6 (BG6S) 09/1989-06/1991	1.6 16V (BG6S) 08/1989-10/1996	
1.8 16V Turbo 4WD (BG8R) 01/1991-07/1994	1.8 16V 4WD 09/1991-07/1994	
1.6 (BG6S) 06/1989-03/1991	1.6 (BG6S) 06/1989-03/1991	
1.6 (BG6S) 06/1989-03/1991	1.6 (BG6S) 06/1989-03/1991	
323 III Station Wagon (BW)		
1.5 (BW105) 01/1987-05/1989	1.5 (BW5W, BW105) 05/1986-05/1989	
1.5 (BW105) 01/1987-05/1989	1.5 (BW105) 01/1987-05/1989	
1.5 (BW5W, BW105) 05/1986-05/1989	1.6 (BW106) 09/1986-10/1995	
1.6 (BW106) 09/1986-10/1995	1.6 4x4 (BWMR) 05/1990-03/1993	
1.6 4x4 (BWMR) 05/1990-03/1993	1.5 (BW5W, BW105) 05/1986-05/1989	
1.6 (BW106) 09/1986-10/1995	1.6 (BW106) 09/1987-10/1989	
1.3 (BW103) 07/1986-04/1990	1.6 (BW106) 09/1992-10/1995	
1.3 01/1986-06/1987		
323 C V (BA)		
1.3 16V 08/1994-09/1998	1.8 16V (BA8P) 08/1994-09/1998	
1.5 16V (BA11) 08/1994-09/1998		
323 III Hatchback (BF)		
1.5 (BF5S) 08/1985-05/1989	1.6 GT (BF106) 08/1985-08/1993	
1.3 (BF103) 09/1985-12/1987	1.6 GT (BF106) 09/1987-10/1989	
1.1 09/1985-10/1989	1.5 (BF105) 09/1987-10/1989	
1.6 GT Turbo 4WD (BF2) 08/1987-10/1989		
1.6 GT Turbo (BF1) 10/1985-08/1993	1.3 (BF103) 09/1987-10/1989	
1.6 GT Turbo 4WD (BF2) 10/1987-11/1991	1.5 i Turbo (BF5S) 08/1985-05/1989	
1.6 (BF106) 09/1987-10/1989	1.5 i (BF5S) 08/1985-05/1989	
1.3 i 09/1985-08/1989	1.3 i 09/1985-08/1989	1.3 (BF103) 09/1985-03/1987
1.6 4WD (BFMR) 06/1986-03/1987	1.3 04/1987-05/1989	
323 F IV (BG)		
1.8 16V GT (BG8S, BG8P) 08/1989-07/1994		
1.8 16V (BG8S, BG8P) 08/1989-07/1994	1.6 (BG6S, BG6P) 09/1989-06/1991	
1.6 16V (BG6S, BG6P) 03/1991-10/1994	1.8 4WD (BG8R) 01/1991-04/1994	
1.8 16V (BG8S, BG8P) 09/1989-03/1993	1.6 (BG6S, BG6P) 04/1991-04/1994	
1.6 (BG6S, BG6P) 04/1991-04/1994	1.6 (BG6S, BG6P) 04/1991-04/1994	
MX-3 (EC)		
1.6 05/1991-10/1993	1.6 i 11/1993-09/1998	
626 III Coupe (GD)		
2.0 16V (GDEP) 12/1987-10/1990	2.0 (GDEP) 09/1987-10/1990	
2.2 12V (GD102) 04/1988-12/1991	2.0 12V (GDEP) 09/1987-12/1988	
2.0 16V (GDEP) 06/1987-09/1989	1.8 (GD8P) 09/1987-08/1991	
323 III Saloon (BF)		
1.5 (BF5S) 08/1985-05/1989	1.3 (BF103) 08/1985-05/1989	
1.5 (BF105) 09/1987-10/1989	1.6 GT (BFMP) 11/1986-10/1989	
1.6 GT (BFMP) 01/1986-12/1988	1.5 i Turbo (BF5S) 08/1985-05/1989	
1.5 i (BF5S) 08/1985-05/1989	1.6 GT Turbo (BFMP) 10/1985-11/1991	
1.3 (BF103) 04/1987-07/1989	1.1 08/1985-04/1990	
1.6 GLX 06/1986-03/1987	1.3 (BF103) 04/1987-05/1989	
626 II Hatchback (GC)		
2.0 (GC10E1) 03/1983-09/1987		
323 C IV (BG)		
1.3 (BG3S) 09/1989-07/1994	1.6 (BG6Z) 09/1989-06/1991	
1.8 16V GT (BG8S) 09/1989-03/1993	1.6 16V (BG6Z) 03/1991-10/1994	
1.8 16V Turbo 4WD (BG8S) 01/1993-07/1994		
1.8 16V Turbo 4WD (BG8S) 09/1990-12/1992	1.3 16V (BG3S) 09/1989-07/1994	
1.8 16V 4WD (BG8S) 11/1991-12/1993	1.3 16V (BG3S) 09/1989-07/1994	
1.8 16V (BG8S) 09/1989-03/1993	1.8 16V (BG8S) 09/1989-03/1993	
1.8 (BG8S) 09/1989-06/1993		
323 S V (BA)		
1.3 16V 08/1994-09/1998	1.5 16V (BA11) 08/1994-09/1998	
1.8 16V (BA11) 08/1994-09/1998	1.5 16V 05/1994-12/1998	
929 II (HB)		
2.0 i GLX (HBES) 10/1984-07/1987		
323 F V (BA)		
1.8 16V (BA8P) 08/1994-09/1998	1.5 16V (BA11) 07/1994-09/1998	
626 III Hatchback (GD)		
2.0 16V (GDEP) 11/1987-10/1990	2.2 12V (GD102) 06/1988-04/1992	
2.0 (GDEP) 09/1987-10/1990	2.0 12V (GDEP) 11/1987-05/1992	
2.0 16V (GDEP) 06/1987-08/1989	1.8 (GD8P) 11/1987-05/1992	
1.8 11/1987-05/1992	1.6 (GD106) 06/1987-05/1992	1.8 11/1987-07/1989
XEDOS 6 (CA)		
1.6 16V 01/1992-03/1994		
121 II (DB)		
1.3 16V (DB3PA) 11/1990-03/1996	1.3 i 16V (DB3PA) 11/1990-03/1996	
626 II (GC)		
2.0 (GC10E1) 03/1983-09/1987		
323 P V (BA)		
1.3 16V 10/1996-09/1998	1.5 16V 10/1996-09/1998	
DEMIO (DW)		
1.3 16V (DW3W, DW19) 08/1998-07/2003		
1.3 16V (DW3W, DW19) 08/1998-07/2003	1.3 i 16V (DW3W) 08/1998-04/2000	
1.3 i 16V (DW3W) 08/1998-04/2000	1.3 16V (DW3W, DW19) 08/1998-07/2003	
1.3 i 16V (DW3W) 08/1998-04/2000	1.3 16V (DW3W, DW19) 08/1998-07/2003	
1.3 i 16V (DW3W) 01/1996-10/2002		
323 F VI Hatchback (BJ)		
1.5 16V (BJ5W) 09/1998-01/2001	1.3 16V (BJ3P, BJ14) 09/1998-01/2001	
1.5 16V (BJ5W) 09/1998-01/2001	1.6 (BJ10M) 01/2001-05/2004	
1.4 (BJ3P) 01/2001-05/2004		
323 S VI Saloon (BJ)		
1.3 16V (BJ3P) 09/1998-01/2001	1.5 16V (BJ5P) 09/1998-01/2001	
1.5 16V (BJ5P) 09/1998-01/2001	1.6 (BJ10M) 01/2001-05/2004	
1.6 (BJ12) 10/2000-05/2004	1.3 (BJ3P) 01/2001-05/2004	
1.3 (BJ3P) 01/2001-05/2004		
E Van (SR2)		
E2000 06/1994-05/2003	E2000 03/1991-05/1994	E2000 03/1991-05/1994
E2000 03/1991-05/1994		
323 II Saloon (BD)		
1.3 (BD103) 11/1980-10/1989		
B-SERIE (UN)		
2.2 8V 4WD 06/1999-11/2006	2.2 11/1999-08/2002	
323 II Hatchback (BD)		
1.6 (BD106) 06/1986-03/1987		
626 II Coupe (GC)		
2.0 (GC10E1) 02/1983-10/1987	2.0 09/1985-10/1987	

2.0 4WD 06/1995-11/1998		